



EPT20-20WA / EPT25-25WA Recommended Spare Parts

ITEM	PART NUM	DESCRIPTION	NAME	Quantity	Serial no	Level	REMARK
1	1120-520009-00	Reversing Switch Wire	反向开关线束	1	327100159-	A	
2	1120-SK	Seal Kit for Cylinder(include item 3,4)	缸盖修理包(包含缸盖密封件)	1		A	
3	1220-520002-1C	2 Way Switch Assembly	钥匙两相开关总成	1	092812-	A	
4	1120-500010-00	Fuse 10A	保险丝 10A	1		A	
5	1115-560017-00	Solenoid Valve	电磁阀	1	042213-	A	
6	1220-560001-00	Inching Switch I	微动开关I	2		A	
7	2112-520003-0C	Inching Switch Assembly	互锁开关、减速开关总成	1	072012-	A	
8	1120-500006-00	Lifting Limit Switch	起升限位开关	1		A	
9	1120-500008-00	Bracket	限位开关板	1		A	
10	1115-341000-00-10	Cap Assembly	上盖总成(带线束)	1	327100159-	B	With Wire
11	1115-340005-00	Travelling Knob R	旋钮右	1	327100159-	B	
12	1115-340004-00	Travelling Knob L	旋钮左	1	327100159-	B	
13	1115-340003-00	Cover	紧急反向开关盖	1	327100159-	B	
14	1121-310004-00	Spring	弹簧	2	327100159-	B	
15	1120-500003-00	Horn	喇叭	1		B	
16	1120-540004-00	Alarm Lamp	报警灯	1	050112-	B	
17	1115-510006-2B-01	Meter 803	电量表 803	1	041512-	B	For Storage Battery
18	1115-510006-2B-02	Meter 803	电量表 803	1	041512-	B	For Maintenance-free Battery
19	2125-210000-00	Brake Assembly	电磁制动器总成	1		B	
20	1120-320000-00	Gas Spring	气弹簧	1		B	
21	1220-520008-0C	Accelerator Assembly	加速器总成	1	327100159-	B	
22	1120-500005-10	Contactora	主接触器	1		B	
23	1115-560002-00	Pump Contactora	泵接触器	1	042213-	B	
24	1115-561001-00	Hydraulic motor Brush	液压电机碳刷	4	042213-	C	
25	1120-200001-00	Driving Wheel	驱动轮	1		C	PU/橡胶
26	1120-133000-10	Single Load Wheel	单承载轮总成	2		C	For Single Wheel
	1120-133000-00	Double Load Wheels	双轮总成	4		C	For Double Wheel
27	1118-140000-00	Caster Assembly	万向轮总成	2	112012-	C	

NOTE:

1) Level A : Suggest to prepare one set for 5 trucks, or 1000 h

2) Level B: Suggest to prepare one set for 10 trucks, or 1000 h

3) Level C: Suggest to prepare one set for 20 trucks, or 2000 h